

Usage

To be used as a coating on PMMA and HSQ resists.

Use clean and separate droppers for dispensing the polymer.

Take care that liquid does not flow into the pipe of spinner vacuum chuck.

Soft bake of the sample at 105°C for 120s on a hot plate

Polymer removal – rinse for 120s in DI water.