

# Usage Policy for Magnesium

1. Material should be stored in refrigerator.
2. Should be loaded to cells as quickly as possible.
3. Hand gloves must be put on while loading cells.
4. Should not be touched by anything, direct transfer from packet to cell.
5. Readily oxidises, so material exposed in air can't be used in MBE.